

Cleaning and care instructions

AFTER EACH DRYING CYCLE



- Clean the lint filter
- Check the drum for foreign objects
- Check the door seal for foreign objects

WEEKLY



OR MORE FREQUENTLY IF REQUIRED

- Check and, if necessary, clean the exhaust air pipes
- Clean the outside of the dryer

USEFUL TIPS



- Don't mix washes
- Before cleaning or servicing the machine, turn the machine off and, if possible, pull the mains plug out.

ADVICE




Don't use solvents, acids or grease, instead use a mild cleaning detergent or a damp cloth.

Self-help



NOTIFICATION ON THE DISPLAY	ACTION
F2	Press the black button on the back of the machine ←
F6	Remove the textiles and restart the programme
F7	Clean the filter
Other error message	Contact Schneidereit Professional customer service



Scan and
select
language

